

Part Number	Part Description	Part Image
MELE3.11	Button Insert Square Green	
MELE3.5	Microswitch 4BR Engine Door	
MELE2.98	Microswitch Bell Push	
MELE3.15	Microswitch Entrance Door	
MELE3.28	Microswitch Entrance Door	
MELE3.24	Microswitch Door	
MELE3.17	Striker Plate Assy Emergency Door	